





WARNING: Do not power up fitting until all work is completed and wired correctly by a qualified electrician.
ALL ELECTRONIC COMPONENTS TO BE REPLACED BY THE MANUFACTURER OR AGENT.
INSTRUCTION SHEET - SHOULD BE RETAINED BY THE END USER


GDNX-1000




GDNX-1000-SW-3K-NL
GDNX-1000-L*-3K
GDNX-1000-L*-3K-NL
GDNX-1000-L*-3K-EP
GDNX-1000-L*-3K-EPs
GDNX-1000-L*-3K-EP-NL
GDNX-1000-L*-3K-EPs-NL
GDNX-1000-L*-3K-DA
GDNX-1000-L*-3K-DA-EPD
GDNX-1000-L*-4K
GDNX-1000-L*-4K-NL
GDNX-1000-L*-4K-EP
GDNX-1000-L*-4K-EPs
GDNX-1000-L*-4K-EP-NL
GDNX-1000-L*-4K-EPs-NL
GDNX-1000-L*-4K-DA
GDNX-1000-L*-4K-DA-EPD




1) Unscrew body from base.




2) Ceiling no more than 3mm deviation. Drill fixing holes into ceiling and screw base into place. Use x6 - M6 bonded washers supplied to ensure IP seal.




3) Wire power cable into terminal block. Max Ø1.8mm gauge




4) Connect flying lead from base into body geartray.



5) Connect Emergency Battery to EM Converter if applicable



6) Screw body to base with T25 screwdriver using M5 captive screws.



7) Uniform bead of anti-pick sealant around base NOT body.